

Fitting Instructions: TOY021H

Vehicle: Toyota RAV4 Wagon (02/13 - ON)

Towing Capacity: 1500kg

Fitting Kit:

- 4x 12 x 40mm Flange bolts
- 2x 'D' shackles
- 2x Towbar Rating Labels

1.	Remove Bumper.
2.	Remove & discard crash support panel. Retain M8 bolts as these are required for towbar fitment.
3.	Remove tie down hook passenger side of car.
4.	Remove exhaust rubbers allowing exhaust to drop away from car.
5.	Remove 'bolted on' exhaust bracket 'attached to' exhaust rear of car.
6.	Mount towbar to underside of chassis using M12 x 1.25 x 40 Flange bolts supplied (2 each side). Do not tighten at this stage.
7.	Using M8 bolts removed in step 2, feed 2 via towbar into back panel. Do not tighten at this stage.
8.	Ensure towbar is central, tighten M12 bolts undercar, then M8 bolts on back panel.
9.	Cut plastic shield (passengers side) as per pictures on page two.
10.	Bumper cut required prior to refitting bumper.
11.	Refit bumper & exhaust.
12.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.

