

Fitting Instructions: TOY030 / TOY098

Vehicle: Toyota Camry Sedan/Wagon (02/1993 – 06/2006)

Toyota Avalon Sedan (06/2000 – 06/2006)

Note: Avalon & Wagon require longer towlug

Towing Capacity: 1250kg

Fitting Kit:

4x	10 x 35mm fine thread bolts, star & flat washers
2x	1¼ x ¾ bolts, nuts star & flat washers
1x	1½ x ¾ bolt, nut, star & flat washer
3x	10mm hole plates
1x	'D' shackle
2x	Towbar Rating Labels

1.	Remove spare wheel & boot mat.
2.	Remove rear tie down hooks & discard.
3.	On certain late model vehicles, removal of exhaust rubber is required so towbar will be positioned correctly.
4.	Mount towbar to existing holes in rear sub frame using 10mm bolts supplied complete with star & flat washers. Tighten.
5.	Drill (10mm) all remaining holes into boot area via towbar, fit corresponding bolts complete with plates then star & flat washers. Tighten.
6.	Re-fit exhaust rubber.
7.	Check all bolts for tightness.
8.	Refit spare wheel & boot mat.
9.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.