

**BORONIA TOWBARS
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
(03) 9752 2642**

**TOY40 FITTING INSTRUCTIONS:
TARAGO VAN 6/2000 –**

REMOVE REAR TIE DOWN HOOKS AND DISCARD.
FEED TOWBAR OVER EXHAUST AND INTO POSITION ALIGNING WITH
EXISTING HOLES IN REAR SUB FRAME, FIT 12mm BOLTS SUPPLIED
COMPLETE WITH SPRING AND FLAT WASHERS.
ONCE ALL ARE FITTED – TIGHTEN.
CHECK ALL BOLTS FOR TIGHTNESS.

FITTING KIT:

6 – 12 x 40 FINE THREAD BOLTS, SPRING AND FLAT WASHERS.
1 – DEE SHACKLE