

**BORONIA TOWBARS
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
(03) 9752 2642**

TOY5H/TOY77 FITTING INSTRUCTIONS
HILUX 2/4WD UTE & TRAY:

MOUNT TOW HITCH TO REAR SUB FRAME EXISTING SIDE HOLES USING 12mm BOLTS SUPPLIED COMPLETE WITH PLATES, SPRING & FLAT WASHERS – TIGHTEN.
DRILL (10mm) HOLES VIA TOW HITCH SUPPORT ARMS THROUGH BASE OF SUB FRAME, FIT 3/8 BOLTS SUPPLIED COMPLETE WITH PLATES, SPRING & FLAT WASHERS – TIGHTEN.
CHECK ALL BOLTS FOR TIGHTNESS.

FITTING KIT:

4 – 12 x 40mm FINE THREAD BOLTS, NUTS, SPRING & FLAT WASHERS.
2 – 11/2 x 3/8 BOLTS, NUTS, SPRING & FLAT WASHERS.
4 – 12mm HOLE PLATES.
2 – 10mm HOLE PLATES.
2 – DEE SHACKLES.