

BORONIA TOWBARS P/L
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
PH: (03) 9752 2642
FAX: (03) 9752 2575

TOY67 FITTING INSTRUCTIONS
TOYOTA HIACE VAN LH51 – YH63 1983 - 89
TOWING CAPACITY 1000KG

REMOVE (FOUR) BOLTS HOLDING BUMPER BAR (2 EITHER SIDE ON CHASSIS).

DROP SPARE WHEEL & REMOVE.

FIT TOWBAR UP TO VEHICLE USING (8mm) BOLTS SUPPLIED.

TIGHTEN.

DRILL (10mm) HOLES VIA TOWBAR THROUGH INTO REAR DOOR AREA.

OPEN TOP HOLES TO ACCEPT TUBES SUPPLIED, FIT BOLTS, PLATES & TUBES.

TIGHTEN.

CHECK ALL BOLTS FOR TIGHTNESS.

FITTING KIT:

4 - 8mm x 35mm BOLTS, SPRING & FLAT WASHERS.

2 - 5" x 3/8" BOLTS, NUTS & SPRING WASHERS.

2 - 3.1/2" x 1/2" SLEEVES.

4 - 10mm FLAT WASHERS.

2 - 3" x 1.1/2" x 3/8" HOLE PLATES.

1 - D SHACKLE.