

BORONIA TOWBARS P/L
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
PH: (03) 9752 2642
FAX: (03) 9752 2575

TOY68 FITTING INSTRUCTIONS
TOYOTA COASTER BUS 1982 - 93
TOWING CAPACITY 1500KG

REMOVE TIE DOWN HOOKS AT REAR OF CHASSIS.
FIT TOWBAR UP TO VEHICLE USING BOLTS SUPPLIED, FIT VIA TOWBAR
THROUGH CHASSIS - TIGHTEN.
DRILL REMAINING (2) HOLES VIA TOWBAR THROUGH THE BASE OF
CHASSIS.
FIT BOLTS & PLATES SUPPLIED - TIGHTEN.
CHECK ALL BOLTS FOR TIGHTNESS.

FITTING KIT:

4 - 10mm x 30mm BOLTS, NUTS & SPRING WASHERS.
2 - 8mm x 35mm BOLTS, NUTS, SPRING & FLAT WASHERS.
2 - 1.1/4" x 3/8" BOLTS, NUTS, SPRING & FLAT WASHERS.
1 - D SHACKLE.