

BORONIA TOWBARS P/L
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
PH: (03) 9752 2642
FAX: (03) 9752 2575

TOY80 FITTING INSTRUCTIONS
TOYOTA COROLLA HATCH / SECA 100 SERIES 09/1994 - ON
TOWING CAPACITY 850KG

REMOVE REAR TIE DOWN HOOK & DISCARD.
REMOVE SPARE TYRE.
MOUNT TOWBAR TO REAR SUBFRAME USING (12mm) BOLTS SUPPLIED VIA EXISTING HOLES IN SUBFRAME - TIGHTEN.
DRILL (10mm) HOLE VIA TOWBAR INTO SPARE WHEEL AREA. FIT BOLT SUPPLIED WITH PLATE. VIA HOLE DRILLED. FIT SPRING WASHER & NUT - TIGHTEN.
REFIT SPARE TYRE.
CHECK ALL BOLTS FOR TIGHTNESS.

FITTING KIT:

4 - 12mm x 40mm BOLTS, SPRING & FLAT WASHERS.
1 - 1.1/4" x 3/8" BOLT, NUTS, SPRING & FLAT WASHER.
1 - 3" x 1.1/2" x 3/8" HOLE PLATE.
2 - 12mm FLAT WASHERS
1 - D SHACKLE.