

**BORONIA TOWBARS
1/12 EDINA ROAD
FERNTREE GULLY
VIC 3156
(03) 9752 2642**

**TOY92 FITTING INSTRUCTIONS
COROLLA AE92 SED / SECA 2/89 – 89/94
TOWING CAPACITY 800 KG**

REMOVE PASSENGER SIDE REAR TIE DOWN HOOK & DISCARD.
REMOVE BOOT CARPET.
FIT TOWBAR TO SUBFRAME USING (8mm) BOLTS, SPRING & FLAT WASHERS SUPPLIED TO PASSENGER SIDE TO EXISTING HOLES.
HOLD TOWBAR FIRM WITH JACK & DRILL (10mm) HOLES VIA TOWBAR & INTO BOOT AREA (DUAL PANEL).
OPEN TOP HOLES TO ACCEPT LONG TUBES, FIT 4 ½ x 3/8 BOLTS TO PLATES SUPPLIED & FEED DOWN THROUGH SUBFRAME.
FIT SPRING WASHERS & NUTS - TIGHTEN.
REMOVE JACK.
DRILL (10mm) REMAINING HOLE PASSENGER SIDE SUBFRAME VIA TOWBAR AGAIN INTO BOOT AREA.
OPEN TOP HOLE TO ACCEPT REMAINING TUBE, FIT BOLT TO PLATE, FEED DOWN THROUGH SUB FRAME, FIT SPRING WASHER & NUT - TIGHTEN.
CHECK ALL BOLTS FOR TIGHTNESS.

FITTING KIT:

3 – 8 x 35mm BOLTS, SPRING & FLAT WASHERS
2 – 4 ½ x 3/8 BOLTS, NUTS, SPRING & FLAT WASHERS
1 – 1 ¼ x 3/8 WIRE TO BOLT, NUT & SPRING WASHER
1 – 3 ½ x ½ TUBE
1 – 3 x ½ TUBE
2 – 3 x 1 ½ x 3/8 HOLE PLATES
1 – DEE SHACKLE