

FORD ESCAPE BA-ZD WAGON 03/01 – 02/12
MAZDA TRIBUTE EP WAGON 03/00 – 01/08

PART NO.

UNT239

1. Remove floor panels and trays from the luggage area.
2. Remove the spare wheel.
3. Remove the Passenger side rear trim to expose the vehicle towbar wiring harness 6 way connector.
4. The 6 way connector should be found in the back rear corner of the vehicle, you may not need to remove the entire trim. Just pull out a couple of inches to pull out the connect on the floor..
5. Connect the towbar wiring harness to the connector.
6. Ensure that the wiring harness connection is hidden behind the trim panel before you lock the trim back together.
7. Locate the rear most grommet in the spare wheel well and pierce a hole in the middle to allow the towbar wiring harness to be fed through the grommet and out under the vehicle. Ensure that the cable running across the back of the vehicle will be hidden when you replace the rear centre trim or floor mat.
8. Returning to the underside of the vehicle, pull the wiring harness through the grommet to meet the required length.
9. Using cable ties secure the wiring harness to meet the required length.
10. Fit the required socket to the wiring harness and mount the plug to the desired position.
11. Test towbar wiring with a trailer testing box
12. Using cable ties secure the wiring harness to meet the required length.
13. Refit Passenger side rear trim.
14. Replace the spare wheel.
15. Replace the floor panels and trays in the luggage area.
16. Test towbar wiring with a trailer testing box.

