

## MITSUBISHI TRITON ML-MQ UTE & CAB CHASSIS 4/07 – ON

PART NO.

**UNT263**

### FITTING GUIDE:

1. This wiring kit is to be connected to Passenger side of the vehicle.
2. Disconnect the tail light harness connectors at the rear.
3. Connect the wiring harness to these connectors.
4. Find a suitable earth point close by and attach.
5. Secure the relays to the vehicle, either by cable tying to existing cables or screw to the vehicle.
6. Route the long black power lead to the battery at the front of the vehicle. Secure the power lead along the way with cable ties, to keep the lead from hanging down.
7. When connecting the power wire to the power source please ensure that the 15amp in line fuse holder is close to the power supply.
8. Fit the required socket to the wiring harness and mount the plug to the desired position.
9. Using cable ties, secure the cable along desired route and the required length.
10. Insert the 15 amp fuse supplied into the fuse holder.
11. Test towbar wiring with a trailer testing box.

