

## **Towbar Wiring Harness Fitting Instructions**

## TOYOTA KLUGER 40 SERIES WAGON 08/07 – 02/14

PART NO.
UNT271

- 1. In the cargo area, fold the third row of seats forward.
- 2. Remove the LHS, RHS and Centre most rear pieces of carpet in cargo area.
- 3. On the passenger side of vehicle remove underfloor storage compartment (two fasteners)
- 4. Locate single white plug that matches plug on harness provided. Note: don't remove any caps on plugs in back of vehicles.
- 5. Secure ECU with double sided tape attached.
- 6. Route five core cable to trailer socket mounting position. Make sure cable is securely attached using zip ties or similar (not supplied) and maintains a safe distance from heat or sharp edges.
- 7. Insert 10amp fuse to "Towing" fuse location. This can be found in fuse box under vehicle bonnet.
- 8. Replace all removed parts in the reverse order.

