

Fitting Instructions: VOLK06H

Vehicle: VW TIGUAN (VOLK06H 2007 – 05/2016)

Towing Capacity: 2000KG

Fitting Kit:

2x	M12 x 1.25 x 40 bolts
2x	M12 X 1.25 X 40 bolts on wire with Flange nuts
2x	D - shackles
2x	Towbar Rating Labels

1.	Remove tail lights
2.	Remove rear number plate & torx beneath, remove torx below each tail light, remove torx in each wheel arch, remove wheel arch trim & scrivet beneath.
3.	Remove utility cover drivers side adjacent to tail light & unplug reverse sensors, displacing rubber gromet allowing wiring to drop clear of car.
4.	Remove bumper
5.	Remove & discard crash support panel
6.	Slide tow hitch arms into chassis aligning holes in towbar with existing holes in chassis rail. Undercar fit M12 bolts to forward most hole in chassis aligning with captive nut in towbar (1 each side). Do not tighten bolts.
7.	Feed remaining M12 bolts on wire into chassis rails via existing rearmost holes in towbar / chassis (1 each side). Undercar fit Flange nuts.
8.	Tighten all bolts
9.	Bumper cut required prior to refitting bumper. Locate centre of bumper & cut 45mm either side of centre up from edge of bumper to the second horizontal line marked on outside of bumper.
10.	Refit items removed in steps 1 to 4
11.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.