

# BTA Towbars

Australia's Towing Equipment Specialist



## Fitting Instructions: VOLK07H

Vehicle: VW TIGUAN 06/16 ON

Towing Capacity: 2000KG

Fitting Kit:

- 2x M12 x 1.25 x 40 Flange bolts
- 2x M12 X 1.25 X 40 bolts on wire & Flange nuts
- 2x D - shackles
- 2x Towbar Rating Labels

1.	Remove tail lights
2.	Remove bumper
3.	Remove & discard crash support panel
4.	Slide tow hitch arms into chassis aligning holes in towbar with existing holes in chassis rail. Undercar fit M12 bolts to forward most hole in chassis aligning with captive nut in towbar (1 each side). Do not tighten bolts.
5.	Feed remaining M12 bolts on wire into chassis rails via existing rearmost holes in towbar / chassis (1 each side). Undercar fit flat / spring washers & nuts.
6.	Tighten all bolts
7.	Bumper cut required prior to refitting bumper. Refer picture below.
8.	Refit bumper and tail lights.
9.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.

