

INSTALLATION INSTRUCTIONS

1476 - TO SUIT FORD TAURUS 96-ON
PLEASE READ INSTRUCTIONS THROUGH BEFORE YOU BEGIN

WARNING : 1. Do not drill, cut weld or otherwise modify the towbar.
2. If you are using electric welding on a motor vehicle, always check that the vehicle is not equipped with electronic engine or instrument management equipment. Failure to do so could destroy any onboard computers. If in doubt, check with the vehicle's manufacturer.

1. Ensure all hardware items have been included.
2. Remove and discard two rear rubber skids one each side but keeping two original bolts.
3. Unclip rubber exhaust mounts one each side and let exhaust hang.
4. Lift towbar into position and insert two original bolts into rear bumper cross member. Do not tighten.
5. Insert tapped plate on wire through hole in side of chassis and fit bolt one on each side.
6. Tighten all bolts to torque listing below.
7. Refit exhaust rubbers.
8. Towbar rating sticker to be conspicuously located on inside rear end of the driver's door. (see diagram below)

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 4.6 Bolt</u>	<u>Grade 8.8 Bolt</u>
	Nm	Nm
M6	3.5	9.5
M8	8.6	21.7
M10	16.9	43.4
M12	29.8	77.3
M16	74.0	189.8

PLEASE NOTE: You must remove the lug unless you are actually towing if it obscures your number plate. Failure to do so may result in a fine.
IMPORTANT: Please see over for safety chain hook-up procedure.

10.4.96

1476 - TO SUIT FORD TAURUS 96-ON