

INSTALLATION INSTRUCTIONS

1950RL - TO SUIT PROTON JUMBUCK UTE

PLEASE READ INSTRUCTIONS THROUGH BEFORE YOU BEGIN

WARNING : 1. Do not drill, cut weld or otherwise modify the towbar.

2. If you are using electric welding on a motor vehicle, always check that the vehicle is not equipped with electronic engine or instrument management equipment. Failure to do so could destroy any onboard computers. If in doubt, check with the vehicle's manufacturer.

Max. Tow Weight: 1000 kg

Max. Ball Weight: 100 kg

1. Ensure all hardware items have been included
2. Remove spare wheel.
3. Remove rear muffler from last three rubber hangers.
4. Remove centre step mounting arm. Retaining the two bolts to step.
5. Lift towbar to sub frame and align holes with captive nuts in sub frame and cross rail.
6. Fit bolts supplied as per diagram and tighten to torque listing.
7. Refit centre step mounting bolts, rear muffler and spare wheel.
8. Towbar rating sticker to be conspicuously located on inside rear end of the driver's door. (see diagram below)

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

