



TOWBAR INSTALLATION INSTRUCTIONS

PART NUMBER QTCL663L

MITSUBISHI TRITON MV MY24 C/CHASSIS

00

PRODUCT DETAILS:

Part Number:	QTCL663L	Maximum Towing Braked:	3500	kg
ECU Number:	04835	Maximum Towing Unbraked:	750	kg
Tail Harness Length Required:	1200 mm	Maximum Static Ball Load:	300	kg
TBM/Lug Part Number:	21161			

FITTING DETAILS:

Towbar Installation Time:	30 Mins.	RPA Disable/Other:	YES
Total Installation Time:	60 Mins.		
Bumper Cut Required:	No		

Note:

- 04943 tail must be used for the trailer detect.
- Trailer fuse located in the engine bay fuse box F6.

TRAILBOSS RECOMMENDS THAT INSTRUCTIONS ARE READ AND UNDERSTOOD COMPLETELY PRIOR TO FITMENT.

BEFORE YOU START:



Check all hardware items have been included refer to assembly diagram.
Please ensure this towbar is only fitted to vehicle models as per Trailboss application guide.

Bumper Cuts

Vehicle and bumper variations can and do occur during vehicle manufacture after initial towbar design. Fitment of towbar to vehicle and accuracy of bumper cut must be assessed prior to any bumper modifications made. Incorrect bumper cuts are not covered under Trailboss warranty.

NOTE: Bumper cuts need to be approached with care, refer to notes below.

- Bumper centreline – where the centreline of the bumper needs to be determined, the installer must assess centre point by measurement of bumper width or determining two symmetrical reference points to give centreline.
- Bumper edge – To assist with accurate bumper cut measurement, reference to the start of the bumper edge is now being commonly used.
 - Measure from bottom edge along bumper and around corner to the 70 mm point (Figure 1).
 - Do not measure from visible bumper front of corner, upwards (Figure 2).



Drilling

- For any required drilling during installation, ensure that the area is clear of fuel, electrical & other components that may be damaged.
- All holes drilled into metal body panels shall have all burrs & swarf removed then coated with a suitable rust preventative paint.

Bolts/Fasteners

- Ensure that all hardware is fastened to correct torque as specified in this fitting instruction.
- All fasteners supplied with this product are used to achieve a specified clamp loading. If replacement is required ensure that fasteners of the same grade and class are used.

NOTE: Achieving correct torque is critical to proper installation and responsibility of the installer. Towbar failures attributed to tension issues from over tightening or under tightening are not covered by Trailboss warranty.

Product Labels


- Towbar load rating sticker provided with this product shall be conspicuously located on inside rear end of the driver's door.

WARNING:

Do not, drill, cut, weld or otherwise modify the towbar.

FOR TOWING PURPOSES ONLY - This towbar is designed and tested by Trailboss to adhere to ADR 62/02 which provides only for the expected load demands of towing.

TOWBAR ASSEMBLY DIAGRAM




ITEM	DESCRIPTION	QTY
1	MITSUBISHI TRITON WELDED ASSY	1
2	SIDE ARM LHS ASSY	1
3	SIDE ARM RHS ASSY	1
4	TRAILER BALL MOUNT	1
5	WASHER PLAIN M12x27x3.0mm	30
6	SET SCREW HEX HD M12x45x1.25P G10.9	22
7	NUT HEX HD M12 X 1.25P GR10	10
8	WASHER PLAIN M12x37x3mm	2

ITEM	DESCRIPTION	QTY
9	LARGE UNIVERSAL PLUG BRACKET KIT	1
10	HITCH BOX COLLAR COVER	1
11	"D" SHACKLE 10mm	2
12	TOWBALL 50mm 3500KG	1
13	SMART PIN SILVER	1
14	COMPLIANCE LABEL	1
15	LOAD RATING LABEL	1
16	WIRE LOOM	1


1. Removing 2x bolts from the rear impact bar.
Repeat it to the other side.

Remove and discards the rear impact bar.




2. Fit the arm to the chassis and loosely secure it 6x M12, 6x small washer, 1x large washer and 1x nut.

Repeat it for the other side.



3. Loosely secure 1x M12 and 1x washer under the side arm.


Repeat it for the other side.




4. Fit the cross tube between the side arms.
Loosely secure it 4x M12, 4x washer and 4 nuts.

Repeat it for the other side.

Torque the fasteners as follows:
M12 x 1.25P – CL 10.9 = 125 Nm



5. Fit the plug bracket to the dropper and secure it with 2x bolts and 2x nut.




IMPORTANT

Due to possible vehicle variations, always confirm any noted vehicle colour wires with a multi-meter to ensure the correct function is identified before soldering or scotch locking. For vehicle wires denoted with two colours (example; RED/GREEN) the first colour will always be the main wire colour while the second colour is the thinner trace colour on the wire.


6. Locate and connect LHS 6 – way taillight connector to trailer patch to mating connector.

Note: LHS taillight connector has Yellow/Black wire.




7. Route the trailer patch along the LHS chassis following the vehicle harness towards the vehicle 8-way and 4-way Prewire connectors.


Note: The vehicle prewire connectors are located above the spare wheel cross frame.



8. Locate and remove the 4-way and 8-way Pre-wire blanking connectors and discard.
9. Connect the trailer patch mating connectors.
10. Connect the waterproof ECU (04835) to the ECU mating connector and secure it above the spare wheel cross frame.
11. Continue to route the trailer patch along the RHS chassis towards the RHS 6-way taillight connector.
12. Connect the RHS mating connector.




13. Remove the fuse cover if the trailer fuse F6 is populated with a 30amp fuse, remove it and replace it with the supplied 20amp fuse.




14. Mount the trailer socket to plug bracket.
15. Route the tail (tail length 1200) towards the trailer patch blue connector.
16. Connect the tail harness (tail length 1200mm) 8-way connector (1) to the trailer patch mating 8-way connector (2).

Cut-off, crimp the tail harness GREY and GREY/BLACK wires (3) to the trailer patch matching GREY and GREY/BLACK wires (4).



-
17. Re-fit all removed parts and secure all fasteners ensuring there are no rattles or squeaks.
 18. Test the trailer patch function using a light board or multimeter.
 19. Secure all harnesses using cable ties (not supplied).





CUSTOMER INFORMATION

PLACE THESE INSTRUCTIONS IN THE
VEHICLE'S GLOVEBOX AFTER INSTALLATION

**THANK YOU FOR PURCHASING TRAILBOSS.
WITH CORRECT MAINTENANCE AND CARE THIS PRODUCT WILL PROVIDE A
LIFETIME OF TROUBLE-FREE OPERATION.**

TOWBAR MAINTENANCE AND CARE:

1. Trailboss recommend that the towbar LUG or TBM (Trailer Ball Mount) Pull Pin and R-clip are removed and stored when not in use. Removal of LUG or TBM (Trailer Ball Mount) is advisable when not in use to assist with any of the following.
 - Ensure rear number plate is not obscured.
 - Allow maximum available departure angle and prevent any potential interference.
 - Prevent possible interference with vehicles reverse sensors or camera detecting a tow ball mount as an obstruction during reversing.
 - Removes towball mount as an obstruction for when moving around the rear of the vehicle.
2. Trailboss recommends routine inspection of your towbar to ensure trouble free towing.
 - Bolt security and tension should be regularly inspected and checked for correct tension. Replace any worn or defective parts with suitable grade & class fasteners. Inspection should be requested to coincide with vehicle major services.
3. It is the owner's responsibility to ensure towing and down ball weight capacities of the towing vehicle are not exceeded.
 - Towing and down ball weights allowable may differ according to model variations. Please refer to owner's manual or vehicle dealer to confirm exact rating for your vehicle model variant.
 - It is not uncommon for the vehicle tow rating to differ from the towbar rating. When this occurs, the lesser rating must be adhered to.
 - For vehicles fitted with enhanced vehicle functions that may be altered/changed when towing i.e Trailer sway mitigation, blind spot detection, adaptive cruise control etc. Please consult owner's manual to understand changes enabled when towing and after towing.

WARRANTY INFORMATION:

Trailboss Towbars are covered by a Lifetime Warranty.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. For further details please contact customer service on 1800 812 017.

PRO SERIES SILENT ANTI-RATTLE HITCH PIN

Your Trailboss towbar is equipped with a Pro Series Silent Anti-Rattle Hitch Pin technology to help reduce towbar tongue rattle in most driving conditions. Please ensure below instructions are understood and routine maintenance is carried out to ensure best towing experience.

Regularly inspect for wear and check the tightness of the Silent Anti-Rattle Hitch Pin. Follow instructions below to re-tighten the nut as necessary when movement and noise in the tow ball mount is noted.

- Before towing, ensure R-Clip is properly installed and hitch pin nut is installed and tensioned. Replacement parts are available from your Pro Series Distributor.

TOWBALL MOUNT REMOVAL/INSTALLATION

STEP 1

Insert Trailer Ball Mount (TBM) (a) into towbar hitchbox (b), aligning hole in TBM shank (c) with hole in hitchbox (d) (Fig. 1)

STEP 2

Insert Silent Anti-Rattle Hitch Pin (e) through hole in hitchbox and hole in TBM shank (g); ensure the locators are inserted into the notches in the hitchbox (Fig. 2)

STEP 3

Screw Silent Anti-Rattle Hitch Pin (f) onto Smart Pin (g); tighten Smart Pin Nut until finger tight, ensuring TBM is restrained from up and down movement.

STEP 4

Tighten Silent Anti-Rattle Hitch Pin Nut by turning nut a further 1/8th of a turn in the clockwise direction using a 24mm spanner (Fig. 4).

STEP 5

Install Silent Anti-Rattle Hitch Pin R-Clip through the hole that provides best clearance or easiest access. (Fig. 5)





Fig. 2

SILENT ANTI-RATTLE HITCH PIN NUT (f)

SILENT ANTI-RATTLE HITCH PIN NUT (e)

R-CLIP

Fig. 3





Fig. 4

Fig. 5




Fig. 6